



## ADDITIONAL OPERATING INSTRUCTIONS-FOLDING THE STROLLER

Set the parking brake to the locked position.

## Model No: MR1781B

Complies with: Australian Standard AS/NZS 2088:2000 (+ CPN 8 of 2007)

**IMPORTANT:** These additional instructions are provided to ensure a better user experience when folding your Max & Rosie Hexa Multi Seat Stroller. Please follow the sequence provided on this page to safely and easily fold your stroller.



Close the 3 sun canopies as shown above.



1. Set the front and middle canopies forward to aproximately 45 degree angle. 2. Undo the velcro on the rear blue cover to

release it from the rear reclining seatback and push it forward to hang inside the stroller.



- 1. Raise all 3 footrests to the HORIZONTAL position.
- 2. Release the rear reclining seatback and push it forward through the inside of the rear canopy.



1. Release the velcro on the top edges of the side protection panels on BOTH SIDES of the stroller.



1. Fold the released side protection panels into the stroller.



1. Remove the front wheels by lifting the front of the stroller and pressing the release buttons for each front wheel assembly



1. Tilt up the safety lock cover with your thumb.



1. Whilst tilting the safety lock cover up, pull both release triggers at the same time and "jerk" the handlebar forward to release it to fold



1. Slowly move the handlebar forward to fold the stroller WHILST 2. Manually adjusting the rear canopy and rear seat forward AS YOU FOLD so it doesn't jamb under the handlebar as the stroller folds.



1. If required, release the rear reclining seat and fold it flat if it is not folded flat already and flatten the front and middle canopies onto the frame.



1. Attach the manual frame folding locks on both sides before manoeuvering or storing the stroller. Ensure the front wheels are store with the stroller so they don't get lost.

CAUTION: When unfolding the stroller ensure the rear seat is unfolded first or it can jamb against the middle seat during unfold. Also ensure the centre canopy is set at 45 degrees before unfolding. Guide the rear canopy up during unfolding to prevent jambing.