

Wooden Gingerbread House Assembly Instructions

Adult Supervision Required

1. Make a U shape with the front, back and base.
2. Hang the 2 sides in the slots in the eaves.
3. Push the roof panels up into their slots, this will require a firm even push to lock them into position. When fully inserted the panels will just touch at the ridge. Put the chimney into its slot.
4. Now that the house is assembled it will require some minor adjustment to make it square, push the sides up to the roof under the eaves. Then use rubber bands as clamps, pull all the panels firmly together. Apply a small amount of glue to the under side of the base on all four sides, and to the top of the walls under the eaves. Allow to dry.

Note: The slots are not straight. When the panels are inserted this bends them slightly locking them into position.