




Step 3



# creativistics

## Easel Leg Set

### ASSEMBLY GUIDE



#### Safety Notice


Ensure this device is used in a safe location.  
Incorrect installation may result in instability and weakness.  
Keep plastic bag and spare parts away from children.




**WARNING**

Adult Assembly Required

ASSEMBLY GUIDE



Step 1



ASSEMBLY GUIDE

Step 2

