











Apple iOS Devices			Apps				
Type	Model	OS Version	 Wonder	 Go	 Blockly	 Path	 Xylo
Tablets	<ul style="list-style-type: none"> • iPad 3, 4 • iPad Air 1, 2 • iPad Mini 1, 2, 3, 4 	8.1+	✓	✓	✓	✓	✓
Phones	<ul style="list-style-type: none"> • iPhone 4s, 5, 5c, 5s, 6, 6 Plus, 6s, 6s Plus • iPod Touch 5 	8.1+	✓	✓	✓	✓	✓

Android Devices			Apps				
Type	Model	OS Version	 Wonder	 Go	 Blockly	 Path	 Xylo
Tablets	<ul style="list-style-type: none"> • Nexus 7 (2013) * • Nexus 9 • Galaxy Note 10.1 • Galaxy Note Pro 12.2 • Galaxy Tab 3 8.0, 10.1 • Galaxy Tab 4 7.0, 8.0, 10.1 • Galaxy Tab Pro 8.4 • Galaxy Tab S 8.4, 10.5 • Nabi 2S • Nabi DreamTab** 	4.4.2+	✓	✓	✓	✓	✓
Phones	<ul style="list-style-type: none"> • Galaxy S4, S5 	4.4.2+	✓	✓	✓	✓	✓

* The Nexus 7 (2013) can only connect to one robot at a time. We recommend that Nexus 7 users purchase Dash only.

**Nabi DreamTab does not support Wonder yet

You may be able to download and use our applications on other iOS and Android tablets and phones, however not all applications will be optimized for these devices.